



RANGE SWITCH SHOWN IN MAXIMUM COUNTERCLOCKWISE POSITION (BAND 1) AS VIEWED FROM FRONT OR KNOB END OF SWITCH.

BAND	RANGE	REMARKS
1	535 - 1600	KX
2	1270 - 4550	KX
3	4450 - 12150	KX
4	11900 - 16500	KX
5	16100 - 22700	KX
6	22000 - 32000	KX

BAND 1 SELECTIVITY SWITCH (S17, 18, 19, 20) SHOWN IN POSITION 1 (BROAD).
 A.V.C.-NOISE LIMITER SWITCH (S21, S22) SHOWN IN MANUAL POSITION WITHOUT NOISE LIMITER.
 OFF-TRANS.-REC. SWITCH (S23, S24) SHOWN IN "OFF" POSITION.

SOCKET CONNECTIONS FOR BATTERY OPERATION
 CONNECT "B" TO PIN #6
 CONNECT "A" (250 TO 300V) TO PIN #7
 CONNECT "A" TO PIN #5
 CONNECT "A" (6V) TO PIN #4

ALL CAPACITOR VALUES GIVEN IN MMF. AND ALL RESISTOR VALUES GIVEN IN OHMS UNLESS OTHERWISE SPECIFIED. TUBE SOCKETS ARE DESIGNATED BY SYMBOL "X" FOR CORRESPONDING TUBE V NUMBER.

W-257026-9

Figure 17—Schematic Diagram